

Архангельск (8182)63-90-72	Ижевск (3412)26-03-58	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Сургут (3462)77-98-35
Астана (7172)727-132	Иркутск (395)279-98-46	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Казань (843)206-01-48	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Набережные Челны (8552)20-53-41	Самара (846)206-03-16	Тула (4872)74-02-29
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Нижний Новгород (831)429-08-12	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Кемерово (3842)65-04-62	Новокузнецк (3843)20-46-81	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Волгоград (844)278-03-48	Краснодар (861)203-40-90	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Вологда (8172)26-41-59	Красноярск (391)204-63-61	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Курск (4712)77-13-04	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Ярославль (4852)69-52-93
Иваново (4932)77-34-06	Киргизия (996)312-96-26-47	Россия (495)268-04-70	Казахстан (772)734-952-31	

www.thiesclima.nt-rt.ru || tcg@nt-rt.ru



Технические характеристики на универсальные блоки ветровой сигнализации

MISCELLANEOUS DEVICES

Wind Alarm Unit Universal

Part number: 4.3244.00.000

The instrument triggers – in connection with an anemometer or/and wind direction sensor – preventive measures to protect wind-endangered objects such as buildings, crane systems, bridges, masts, green houses, louvers/shutters, awnings etc.

Through mode selections and parameter settings the warn unit can meet diverse requirements.

Option 1:

1 x wind speed alarm

here, a threshold value of the wind speed is set, when the preventive measure shall be triggered.

Option 2:

as 1, however with 2 wind speed alarms (for ex. for early warning and main alarm)

Option 3:

1 x wind direction-dependent wind speed alarm. Here, a threshold value of the wind speed is set, and is linked with the selected wind sector, from which the protected object might be endangered.

Option 4:

as 3, however with 2 x wind direction-dependent wind speed alarms for application with a different alignment of the protected objects.

The setting/operation is carried out via button or via the serial interface.



Specification

Part number: 4.3244.00.000

Data input analog

Wind speed	4 ... 20 mA
------------	-------------

Wind direction	4 ... 20 mA
----------------	-------------

Data input digital

Wind speed	0 ... 1600 Hz
------------	---------------

Wind direction	Thies-Seriell-Synchron
----------------	------------------------

Wind alarm parameter

Wind alarm range	0 ... 50 m/s
------------------	--------------

Resolution	1 m/s
------------	-------

Switch-on-delay	0 ... 120 sec
-----------------	---------------

Switch-off-delay	0 ... 240 min
------------------	---------------

Wind alarm output

Relay 1	for ex. early warning
---------	-----------------------

Relay 2	for ex. main alarm
---------	--------------------

Relay load (AC)	5 A / 250 VAC cos =1
-----------------	----------------------

Relay load (DC)	5 A / 30 VDC
-----------------	--------------

Interface

Type	RS485
Data format	8N1
Baud rate	300 Baud ... 115200 Baud

General

Ambient temp.	-20 ... +50 °C non condensing
Mounting	DIN rail mounting
Protection	IP 20
Dimension	105 x 86 x 85 mm
Weight	0.65 kg

Versions

No other versions of this product are available.

Accessories

No accessories are available for this product.

Архангельск (8182)63-90-72	Ижевск (3412)26-03-58	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Сургут (3462)77-98-35
Астана (7172)727-132	Иркутск (395)279-98-46	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Казань (843)206-01-48	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Набережные Челны (8552)20-53-41	Самара (846)206-03-16	Тула (4872)74-02-29
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Нижний Новгород (831)429-08-12	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Кемерово (3842)65-04-62	Новокузнецк (3843)20-46-81	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Волгоград (844)278-03-48	Краснодар (861)203-40-90	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Вологда (8172)26-41-59	Красноярск (391)204-63-61	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Курск (4712)77-13-04	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Ярославль (4852)69-52-93
Иваново (4932)77-34-06				
	Киргизия (996)312-96-26-47	Россия (495)268-04-70	Казахстан (772)734-952-31	

www.thiesclima.nt-rt.ru || tcg@nt-rt.ru